

## K-Kraft Super Winder

[www.fancyquilt.com](http://www.fancyquilt.com)


## Threading

From the top of the cone up through loop in the stand-

Through the eyelet of the tension assembly-

Around the back of the tension disks ( be sure pull the thread snugly between the 2 disks )-

To the bottom of the bobbin and wind around a few times to secure or through the hole, whichever method you prefer (the motor turns clockwise).



## Controls



### Power Switch

Power on/off for winder (When initially powered on the motor will run for a second then stop).

### Speed Control Knob

Sets the speed of the motor 1=Slow 6=Fast

Between 3 and 4 is a good place to start

### Start / Stop

Starts the motor if it is stopped — Stops the motor if it is running

### Auto Fill

A feature that automatically stops the motor when the bobbin is full.

There are 2 selections for handling 2 different bobbin types.

### Setting Auto fill

- Power on
- Put slider switch to 1 or 2 depending on which one is being changed.
- Thread to wind the bobbin
- \*Long Push and hold the start/stop button , then release.
- \*When the bobbin is at the desired fullness, quick push the start/stop button again.

This procedure can be repeated at any time to re-set the shut off point.

The setting will remain (even when the power is off) until the setting procedure is repeated.

The setting is determined by counting the revolutions of the bobbin so the speed will not change the amount of thread on the bobbin. It will just take more or less time to fill the Bobbin. (If different weights of thread are used, you would need to reset).

\* Quick push = push and release——Long push = 5 Seconds